



## YULEYS® are Easy to Use and Easy to Remove



1. PLACE: Place both YULEYS® next to each other on the floor.



2. STEP IN: Step into them one at a time, toe-first, pushing down on heel until firmly locked into place. It's that easy!



3. STEP OUT: To remove YULEYS® step on opposite heel tab and lift foot out. Repeat on other foot. Convenient hands-free removal.

## YULEYS® Are Easy to Clean

Caring for your YULEYS® is simple, making them ideal for busy companies and workers. Simply remove your YULEYS® rinse them off, and let them dry until the next time you need them.

## Just Your Size

Measure the sole length of your boots by putting the toe against a wall or straight surface and make note of where the heel ends, then measure this distance exactly with a ruler or measuring tape. Find the length on the chart below and you are good to go. If the length falls in a range between two YULEYS® sizes, select the smaller size.

Work Boot/Shoe Sole Length	YULEYS® Sizes
10 in. (25.5 cm) - 10 1/2 in. (26.7 cm)	A/4 - <i>Coming Soon</i>
10 1/2 in. (26.7 cm) - 11 in. (27.9 cm)	B/5 - <i>Coming Soon</i>
11 in. (27.9 cm) - 11 3/4 in. (29.8 cm)	C/6 - <i>Coming Soon</i>
11 3/4 in. (29.8 cm) - 12 5/16 in. (31.3 cm)	D/7
12 5/16 in. (31.3 cm) - 12 5/8 in. (32.0 cm)	E/8
12 5/8 in. (32.0 cm) - 12 15/16 in. (32.9 cm)	F/9
12 15/16 in. (32.9 cm) - 13 5/16 in. (33.8 cm)	G/10
13 5/16 in. (33.8 cm) - 13 3/4 in. (34.9 cm)	H/11
13 3/4 in. (34.9 cm) - 14 3/16 in. (36.0 cm)	I/12

Call **1-877-MY ARMOR** or visit **YULEYS.com**

YULEYS® are designed for indoor use. Outdoor use is not recommended and may result in compromised safety. Do not attempt to drive or operate any vehicle or machinery while wearing. YULEYS® are not intended to be a substitute for safety footwear and are only designed as a convenience for protecting indoor flooring from outside contaminants.